

SDongleA-05 Smart Dongle Quick Guide (WLAN-FE)

Document Issue: 11
Part Number: 31500HMN
Release Date: 2022-12-10



Copyright © Huawei Digital Power Technologies Co., Ltd. 2022. All rights reserved.

NOTICE


The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

- SDongleA-05 (Dongle for short) is a smart communications expansion module that works with Huawei inverters to implement communication between inverters and the management system using WLAN or FE.
- A Dongle can be used for device cascading using RS485 communication (inverter cascaded or inverters cascaded with other devices). A maximum of 10 devices can be cascaded.
- When multiple inverters are cascaded, only one Smart Dongle or one SmartLogger is allowed.

1 Communication Scenario

NOTE

- Inverters with different appearances are used in the same communication scenario. The inverters in this document are used as an example.
- In the networking, the inverter where the Dongle is installed is the master inverter, and other inverters are slave inverters. Slave inverters can communicate with the Dongle through cascading.
- In the communications scenario, ensure that the wireless network of the inverter and router is not disturbed and that the signal is normal.



Number of devices in the RS485 communication scenario

Limit	Actual Number	
	Number of Slave Inverters	Number of Non-Inverter Devices (Such as Power Meters)
Maximum Number of Devices That Can Be Connected to the Dongle		
10	$n \leq 9$	$\leq 9 - n$
3 (with energy storage)	$n \leq 2$	$\leq 2 - n$
3 (with single-phase inverters)	$n \leq 2$	$\leq 2 - n$

If devices are connected to the 485B2 and 485A2 ports of the master inverter, the devices are not included as cascaded devices.


Inverter Model Requirements

Master Inverter	Slave Inverter
SUN2000-(2KTL-6KTL)-L1 SUN2000-(3KTL-20KTL)-M0 SUN2000-(3KTL-12KTL)-M1 SUN2000-(8KTL-20KTL)-M2 SUN2000-(20KTL-40KTL)-M3 SUN2000-(50KTL-ZHM3, 50KTL-M3) SUN2000-(12KTL-25KTL)-M5	SUN2000-(2KTL-6KTL)-L1 SUN2000-(3KTL-20KTL)-M0 SUN2000-(3KTL-12KTL)-M1 SUN2000-(8KTL-20KTL)-M2 SUN2000-(20KTL-40KTL)-M3 SUN2000-29.9KTL/36KTL SUN2000-33KTL-A SUN2000-50KTL/60KTL-M0 SUN2000-(50KTL-ZHM3, 50KTL-M3) SUN2000-(12KTL-25KTL)-M5

2 Installation and Commissioning


1. Install the Dongle.

WLAN Communication



FE Communication

You are advised to use a CAT 5E outdoor shielded network cable (outer diameter < 9 mm; internal resistance $\leq 1.5 \Omega/10$ m) and shielded RJ45 connectors.



Operation	LED		Remarks	Description
	Color	Status		
Installing the Dongle	N/A	Off	Normal	The Dongle is not secured or is not powered on.
	Yellow (blinking green and red simultaneously)	Steady on		The Dongle is secured and powered on.
	Red	Blinking at short intervals (on for 0.2s and then off for 0.2s)	Abnormal	The parameters for connecting to the router are to be set.
	Red	Steady on		The Dongle is faulty. Replace the Dongle.
	Blinking red and green alternatively	Blinking at long intervals (on for 1s and then off for 1s)		No communication with the inverter • Remove and insert the Dongle. • Check whether inverters match the Dongle. • Connect the Dongle to other inverters. Check whether the Dongle or the USB port of the inverter is faulty.

NOTICE

Before setting parameters, ensure that the AC and DC side of the inverter has been powered on.

2. Install the FusionSolar app. Perform the **Setup wizard** operations. If you have performed such operations, skip this step. If not, you can scan the QR code below to obtain the app quick guide which describes the **Setup wizard** operations.




Operation	LED Indicator		Remarks	Description
	Color	Status		
Router connection settings	Green	Blinking at long intervals (on for 0.5s and then off for 0.5s)	Normal	Connecting to the router
	Red	Blinking at short intervals (on for 0.2s and then off for 0.2s)	Abnormal	Failed to connect to the router. Check whether the parameters for connecting the Dongle to the router are properly set. If not, set the parameters correctly.
Management system settings	Green	Steady on	Normal	Successfully connected to the management system.
	Red	Blinking at long intervals (on for 1s and then off for 1s)	Abnormal	Failed to connect to the management system. Check whether the parameters for connecting inverters to the management system are properly set. If not, set the parameters correctly.
	Green	Blinking at short intervals (on for 0.2s and then off for 0.2s)	Normal	The inverter is communicating with the management system through the Dongle.

3. Commission the inverter locally via the Smart Dongle WLAN. If the Smart Dongle WLAN is disabled, log in to the FusionSolar app and tap the plant name on the **Home** screen to access the plant screen. Tap **Devices** and then tap **SDongleA-05**. Choose **O&M Authorization > WLAN wakeup > Confirm** to enable the Smart Dongle WLAN.

NOTE

If the inverter has a built-in WLAN module, the Smart Dongle WLAN is disabled by default. If the inverter does not have a WLAN module, the Smart Dongle WLAN is enabled by default.



Performance Parameters

Model on the Nameplate	SDongleA-05
Maximum Number of Devices	10 (Inverters are connected with each other over RS485.)
Network Port	10/100M Ethernet port
Encryption Mode	Not encrypted, WPA, WPA2, WPA/WPA2
Installation Mode	Plug-and-play (applicable to inverters only)
Indicator	LED
Dimensions (W x H x D)	146 mm x 48 mm x 33 mm
Net Weight	90 g
Ingress Protection Rating	IP65
Typical Power Consumption	2.5 W
Standard and Frequency Band	802.11b, 802.11g, 802.11n, 2.412 GHz to 2.484 GHz
Operating Temperature	-30°C to +65°C
Relative Humidity (Non-condensing)	5%~95% RH
Storage Temperature	-40°C to +70°C
Highest Altitude	4000 m

3 Obtaining Documentation

NOTE

You can obtain the latest version of this document by scanning the following QR codes.

